

VISU-Link Meter Reading Explanation

The Visu-Link is an electronic reading device that interprets the data from the meter register wheel bank and displays the reading remotely.

It is important that the number of dials to be read be understood by the meter reader. **The 6 or 8 digit reading must be interpreted differently depending on the meter size and unit of measurement of the meter itself.** Most registers will have 6 digit reading. If there are 8 digits, the value of the first 6 digits remains the same. **Please be sure that the person reading the meter understands what size the meter is so that the correct unit of measurement can be applied to the reading.** The table below will indicate what the last digit represents.



The 5/8" meter with a six digit register in US Gallons has a printed zero to the right of the wheel bank. The 6 digit read is in tens of gallons

5/8 – 1" US Gallons

(6 digit)						(8 digit)	
0	0	0	0	0	0	0	0
1M	100K	10K	1K	100	10	1	0.1

5/8 – 1" Cubic Feet

(6 digit)						(8 digit)	
0	0	0	0	0	0	0	0
100K	10K	1K	100	10	1	0.1	0.01

1 1/2" – 4" US Gallons

(6 digit)					(8 digit)		
0	0	0	0	0	0	0	0
10M	1M	100K	10K	1K	100	10	1

1 1/2" – 4" Cubic Feet

(6 digit)						(8 digit)	
0	0	0	0	0	0	0	0
1M	100K	10K	1K	100	10	1	0.1

6" and Larger US Gallons

(6 digit)						(8 digit)	
0	0	0	0	0	0	0	0
100M	10M	1M	100K	10K	1K	100	10 Fixed 0

6" and Larger Cubic Feet

(6 digit)						(8 digit)	
0	0	0	0	0	0	0	0
10M	1M	100K	10K	1K	100	10	1